

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure
for IPC_G6202-B0001P97D1911C69/GIPC-B6202.2.68.C03269.210221
IPC_G6203-B0001P77D1911C69.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information.....	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table	3
1.4 Feature and Change Description	4
2 Version Upgrade Procedure	4
2.1 Upgrade Overview.....	4
2.1.1 Version Upgrade Environment.....	4
2.2 Upgrade Procedure	4
2.2.1 Upgrade Through the Web	4

1 Version Information

1.1 Version Number

IPC_G6202-B0001P97D1911C69

GIPC-B6202.2.68.C03269.210221

IPC_G6203-B0001P77D1911C69

1.2 Release History

Table1Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_G6202-B0001P97D1911C69	NA	2021-02-25	Initial release

Version No.	Basic Version No.	Released On	Remarks
GIPC-B6202.2.68.C03269.210221	NA	2021-02-25	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_G6203-B0001P77D1911C69	NA	2021-02-25	Initial release

1.3 Version Mapping Table

Table2Product models and corresponding versions

Product Series	IPC Series
Series	Videosec
Models	Videosec series: Videosec-IPW-2225IQ-40SWX
Target file name	IPC_G6202-B0001P97D1911C69.zip

Product Series	IPC Series
Series	Videosec
Models	Videosec series: Videosec-PTZ-675IQ-X4SWAL
Target file name	GIPC-B6202.2.68.C03269.210221.zip

Product Series	IPC Series
Series	Videosec
Models	Videosec series: Videosec-IPW-2128IQ-28WAL
Target file name	GIPC-B6202.2.68.C03269.210221.zip

1.4 Feature and Change Description

None.


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup>Maintenance>Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade

Upgrade File ☐ Upgrade Boot Program

Device Restart

Restart the device.

☐ Enable Auto Restart

Config Management

Keep current network and user settings and restore other settings to defaults.

Importing

Exporting

Diagnosis Info

Storage Path

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_G6202-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.