

Release Notes

Release Notes

Keywords: Version information, version upgrade

Abstract: This document provides detailed version information and upgrade procedure for

IPC_HCMN2103-B0018P30D1705C05/ IPC_HCMN2105-B0007P30D1705C05/

IPC_Q1203-B0001P60D1705C30.

Acronym:

Acronym	Full Name
IPC	IP Camera

Content

1 Version Information	3
1.1 Version Number	3
1.2 Release History	3
1.3 Version Mapping Table	3
1.4 Feature and Change Description	4
2 Version Upgrade Procedure	4
2.1 Upgrade Overview	4
2.1.1 Version Upgrade Environment	4
2.2 Upgrade Procedure	4
2.2.1 Upgrade Through the Web	4

1 Version Information

1.1 Version Number

IPC_HCMN2103-B0018P30D1705C05

IPC_HCMN2105-B0007P30D1705C05

IPC_Q1203-B0001P60D1705C30

1.2 Release History

Table 1 Released versions

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN2103-B0018P30D1705C05	IPC_HCMN2103-B0017P20D1702C25	2017-11-10	Improved release

Version No.	Basic Version No.	Released On	Remarks
IPC_HCMN2105-B0007P30D1705C05	NA	2017-11-10	Initial release

Version No.	Basic Version No.	Released On	Remarks
IPC_Q1203-B0001P60D1705C30	NA	2017-11-10	Initial release

1.3 Version Mapping Table

Table 2 Product models and corresponding versions

Product Series	IPC Series
Series	PTZ-622、PTZ-625
Type	PTZ-622 Series: PTZ-6222ER-X30PB
	PTZ-625 Series: PTZ-6252SR-X33U
Target file name	IPC_HCMN2103-B0018P30D1705C05.zip

Product Series	IPC Series
Series	PTZ-625
Type	PTZ-625 Series: PTZ-6258SRE-X22P
Target file name	IPC_HCMN2105-B0007P30D1705C05.zip

Product Series	IPC Series
Series	IPF-868
Type	IPF-868 Series: IPF-868ER-VF18-B
Target file name	IPC_Q1203-B0001P60D1705C30.zip

1.4 Feature and Change Description

None.


2 Version Upgrade Procedure

2.1 Upgrade Overview

2.1.1 Version Upgrade Environment

1. Network Architecture for Upgrade

Figure 1 Network architecture



As shown in this figure, the version files are stored on the PC that is connected to the IPCs through the network.

2.2 Upgrade Procedure

2.2.1 Upgrade Through the Web

- (1) Log in to the Web interface as **admin** (default password: 123456).
- (2) Click **Setup > Maintenance > Device Maintenance**. The **Device Maintenance** page is displayed.

Firmware Upgrade

Upgrade File ☐ Upgrade Boot Program

Device Restart

Restart the device.

☐ Enable Auto Restart

Config Management

Keep current network and user settings and restore other settings to defaults.

Importing

Exporting

Diagnosis Info

Storage Path

- (3) Click **Browse** in the **Firmware Upgrade** area. In the **Select** dialog box that appears, select the upgrade file package, for example, IPC_HCMN2103-XXXXX.zip, and then click **Open**.
- (4) Click **Upgrade**. You cannot operate on other pages during the upgrade process.
- (5) Wait till the upgrade is completed. A message appears to indicate successful upgrade and prompt you to log in again after the device restarts.

No part of this manual may be reproduced or transmitted in any form or by any means without prior written consent of our company.

The information in this manual is subject to change without notice.